


M4.55 M4.56 **Brandstofpomp** **Fuel pump**

pos.	qty	part	benaming	description
1	1	**STM9972**	Brandstofpomp cpl.	Fuel pump cpl.
2	4	**STM7969**	Huis	Housing
3	4	**STM9968**	Houder	Holder
4	4	**STM9963**	Veer	Spring
5	4	**STM7972**	Pakking	Gasket
6	4	**STM9964**	Klep	Valve
7	4	**STM9965**	Element	Element
8	4	**STM7975**	Geleider	Sleeve
9	4	**STM7976**	Zitting	Seat
10	4	**STM7977**	Veer	Spring
11	4	**STM7978**	Stoter	Tappet
12	4	**STM7979**	Zitting	Seat
13	4	**STM7980**	O-ring	O-ring
14	3	**STM7981**	Stelplaat	Plate
15	3	**STM7982**	Bout	Bolt
16	1	**STM7983**	Schroef	Screw
17	1	**STM7985**	Ring	Washer
18	1	**STM7986**	Shim	Shim
19	1	**STM7987**	Pen	Pin